

SPEC-D *Tuning*

2004-2011 CHEVY COLORADO GMC CANYON BUMPER LIGHTS INSTALLATION INSTRUCTIONS

*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

*Please wear protection before you work on your vehicle.

*An assistant is useful when removing the front bumper from your vehicle.

*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



TOOLS AND SUPPLIES REQUIRED

Flathead Screwdriver

Product Part Numbers:

2LC-COL04JM-TM

2LC-COL04-TM



2004-2011 CHEVY COLORADO GMC CANYON BUMPER LIGHTS INSTALLATION INSTRUCTIONS

- *If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.
- *Please wear protection before you work on your vehicle.
- *An assistant is useful when removing the front bumper from your vehicle.
- *Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.
- *Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. Open the front hood



2. Release the retaining clip



3. Release the bumper light retaining clip



4. Disconnect the bumper light harness



5. Remove the bumper light



6. Transfer the bumper light harness to the new bumper light



7. Connect the bumper light harness



8. Place the new bumper light in the stock location



9. Please repeat the steps in order from 1 to 8 for the opposite side. The installation is now complete