

INSTALLATION & CARE

2019-UP DODGE RAM 2500HD/3500HD DRL LIGHT BAR HEADLIGHT WITH LIGHT EFFECT

BEFORE INSTALLATION:

- If you experience any difficulties that the instructions did not cover, please seek assistance at a local automotive shop.
- Please wear proper protective equipment before you work on any vehicle.
- An assistant is recommended when removing the front bumper from your vehicle.
- Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.
- Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED

| | | | |
|---------------------|----------------------|------------------|----------------------|
| 1/4" Ratchet | 10 mm Socket | Trim Pad Remover | Flathead Screwdriver |
| | | | |
| 6" Socket Extension | 24" Socket Extension | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

PRODUCT NUMBER

2LH-RAM1925-G3-RS
2LH-RAM1925G-G3-RS
2LH-RAM1925JM-G3-RS
2LH-RAM1925SM-G3-RS

LET'S START THE INSTALLATION



STEP 1A

Remove the fourteen plastic fasteners on the radiator upper support cover



STEP 1B

Remove the fourteen plastic fasteners on the radiator upper support cover




STEP 1C

Remove the fourteen plastic fasteners on the radiator upper support cover



STEP 2

Remove the radiator upper support cover



STEP 3A

Remove the ten 10mm bolts at the top of the upper grille trim



STEP 3B

Remove the ten 10mm bolts at the top of the upper grille trim



STEP 3C

Remove the ten 10mm bolts at the top of the upper grille trim




STEP 4

Remove the upper grille trim



STEP 5A

Grab the edge with both hands and pull forward to remove the body trim, it's a little difficult to take out



STEP 5B

Grab the edge with both hands and pull forward to remove the body trim, it's a little difficult to take out



STEP 5C

Grab the edge with both hands and pull forward to remove the body trim, it's a little difficult to take out




STEP 6

Remove the two 10mm bolts on the lower grille trim, one on each side



STEP 7A

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 7B

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 7C

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 7D

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper




STEP 7E

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 7F

Remove the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 8

Remove the lower grille trim



STEP 9A

Remove the eight 10mm bolts at the bottom of the front grille, four on each side



STEP 9B

Remove the eight 10mm bolts at the bottom of the front grille, four on each side



STEP 10A

Remove the six 10mm bolts at the top of the front grille




STEP 10B

Remove the six 10mm bolts at the top of the front grille



STEP 11

Unseat the front grille upper leg



STEP 12

Remove the front grille



STEP 13A

Remove the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper



STEP 13B

Remove the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper



STEP 13C

Remove the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper




STEP 14

Remove the 10mm bolt and the plastic fastener at the top of the headlight



STEP 15

Unseat the factory headlight housing



STEP 16A

Unlock the headlight harness lock



STEP 16B

Disconnect the headlight harness, and then remove the factory headlight housing



STEP 17

Connect the headlight harness to the new headlight




STEP 18

Seat the new headlight assembly in place



STEP 19

Reinstall the 10mm bolt and the plastic fastener at the top of the headlight



STEP 20A

Reinstall the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper




STEP 20B

Reinstall the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper




STEP 20C

Reinstall the plastic fastener and the 10mm bolt at the bottom of the headlight, in between the fender and front bumper



STEP 21

Please repeat the steps from 13 to 20 for the opposite side



STEP 22

Remove the under hood fuse box cover and locate #95 fuse



STEP 23

Remove the #95 fuse



STEP 24

Install the #95 10 amp fuse to the ACC wire fuse empty spot



STEP 25

Install the ACC wire fuse to the #95 fuse spot and reinstall the fuse box cover



STEP 26

Connect the ACC wire to the LH headlights connector



STEP 27

Connect the ACC wire to the RH headlights connector and start the car to make sure the LED light bar is working



STEP 28

Cable ties the losse wires



STEP 29A

Start the car to make sure the LED light bar is working before reinstalling the front grille



STEP 29B

Reinstall the front grille



STEP 30

Attach the front grille upper leg in place



STEP 31A

Reinstall the six 10mm bolts at the top of the front grille



STEP 31B

Reinstall the six 10mm bolts at the top of the front grille



STEP 32A

Reinstall the eight 10mm bolts at the bottom of the front grille, four on each side



STEP 32B

Reinstall the eight 10mm bolts at the bottom of the front grille, four on each side



STEP 33

Reinstall the lower grille trim



STEP 34A

Reinstall the seven 10mm nuts on the lower grille trim from underneath the front bumper




STEP 34B

Reinstall the seven 10mm nuts on the lower grille trim from underneath the front bumper



STEP 35

Reinstall the two 10mm bolts on the lower grille trim, one on each side



STEP 36

Reinstall the body trim



STEP 37

Reinstall the upper grille trim



STEP 38A

Reinstall the ten 10mm bolts at the top of the upper grille trim



STEP 38B

Reinstall the ten 10mm bolts at the top of the upper grille trim



STEP 38C

Reinstall the ten 10mm bolts at the top of the upper grille trim



STEP 39

Reinstall the radiator upper support cover



STEP 40A

Reinstall the fourteen plastic fasteners on the radiator upper support cover



STEP 40B

Reinstall the fourteen plastic fasteners on the radiator upper support cover



STEP 40C

Reinstall the fourteen plastic fasteners on the radiator upper support cover



STEP 41



Close the hood to complete the installation

